

DIRECTIONS FOR USE

Read entire label and use in accordance with ALL of the precautionary statements and directions.

ZeoSand® Cleaner features a combination of cleaning materials to renew and clean ZeoSand® Filter Media. ZeoSand® Cleaner releases trapped ammonia and renews chloramine holding capacity. Mineral and scale are dissolved and flushed away. Oily residues are removed by the wetting and detergent action of ZeoSand® Cleaner. Regular use of ZeoSand® keeps ZeoSand® filter Media operating at maximum efficiency.

Use ZeoSand® Cleaner for spring opening, winter closing, ZeoSand® Cleaner should also be used when oils and minerals buildup in the filter or chloramine become a problem. A clean ZeoSand® filter is the best insurance policy for clean and clear water.

HOW TO USE

Prepare product for use OUTDOORS. Do not splash product on counter tops or flooring material. Dissolve 1 pound of ZeoSand® Cleaner per 2 gallons of luke-warm water in a plastic bucket; use a plastic or wooden stirrer. After backwashing the filter, turn off the filter pump and drain the filter. Remove lint pot lid remove all debris. With the filter handle in the backwash position, turn the pump on and pour the ZeoSand® Cleaner solution into lint pot until the ZeoSand is completely covered - check site glass for level. Turn off pump and allow the ZeoSand® Cleaner solution to remain in the filter for 12 hours. Then, backwash until the backwash water is clear of all foam. Turn the handle to filter and return to normal filter operation. NEVER add ZeoSand® Cleaner powder or solution to the pool water - use in filter ONLY.

PRECAUTIONARY STATEMENTS

CAUTION: ACIDIC EYE AND SKIN IRRITANT. HARMFUL IF SWALLOWED. Contains sodium bisulfate, citric acid, and salt. Avoid contact with eyes, skin, or clothing, ingestion, and inhalation. Do not mix with other chemicals. Provide product container information to any needed medical personnel.

FIRST AID:

IF IN EYES

- Flush with plenty of water for 15 minutes
- Get prompt medical attention

IF ON SKIN OR CLOTHING

- Flush with plenty of water for 15 minutes.
- Wash with soap and water
- If irritation persists get medical attention
- Wash contaminated clothing before reuse

IF SWALLOWED

- Drink large quantities of water
- Do not induce vomiting
- Call a physician immediately

IF INHALED

- Remove victim to fresh air
- Call a physician

STORAGE AND DISPOSAL

STORAGE: Keep this product in its original, tightly closed container when not in use. Keep out of reach of children.

EMPTY CONTAINER DISPOSAL: Do not reuse container. Place in trash container.

ZEO, Inc.
P.O. Box 2353
McKinney, Texas 75070
www.zeoinc.com

NET. WT. 2 lbs. (907 g)

ZeoSand® Cleaner

Renews & Cleans ZeoSand® Filter Media



ZEO

- Regenerates Chloramine Control
- Removes Minerals, Scale, & Oils
- Renews Filtration Efficiency

Use at spring opening, winter closing, or whenever a thorough cleaning is needed.

Maintains ZeoSand® in the best operating condition, for clear and clean water.

Keep Out of Reach of Children

CAUTION: EYE AND SKIN IRRITANT / HARMFUL IF SWALLOWED

See First Aid Statement & Additional Precautions On Back Panel